

Installation of your Handspray



1 Most toilets have a flex pipe.



2 Remove flex pipe.



4 Fit handspray hose to water diverter, ensuring you insert black washer.



3 Place dual check on tap, ensuring you insert into the bottom of the backflow dual check.



5 Fit water diverter to Cistern, ensuring you Insert Black Washer.



6 Connect Flex Pipe.



Now all that's left to do is screw on the Handspray holder to the wall! and place your Handspray into it.

Hand Sprays shall be installed in accordance with The National Construction Code – Volume Three and where used as a douche spray are classified as High Hazard and appropriate additional backflow prevention will be required such as RPZ valve.

Operation of your Handspray



The Handspray water diverter has been designed with your safety in mind.

In position 1 all water supply to the Cistern and Handspray is shut off.

In position 2 water supply is to the Cistern only.

When you are **not** using the Handspray please place the water diverter into position 2. When you are about to use your Handspray turn the tap to adjust the waterflow for your personal comfort, when finished place back to position 2, the Cistern only position.

The[®]
BIDET
SHOP